

ULTI Home Control

User Guide





Outline

Schneider ULTI Home Control App

New device installation and settings		
iOS device P	24	
Android device P	2.6	
User interface P	2.9	
Reminder P	2.21	

ULTI Home Control – device installation and settings

In order to access the ULTI Home Control, you must download the app to a mobile device and set up the connection. The app is compatible with iOS and Android devices.

iOS

Download and install the app

Search for "ULTI" at the App Store or scan the QR code below and download the app.




iOS



QR code (iOS devices)

Connect to the Wi-Fi network

After downloading and installation, connect your mobile device to the same Wi-Fi network used by ULTI Home Control.



Android

Download and install the app

A technical consultant will install and download the ULTI Home Control app for you.

Connect to the Wi-Fi network

After downloading and installation, please connect your mobile device to the same Wi-Fi network used by ULTI Home Control.



Login to ULTI Home Control

Follow steps below to login to ULTI Home Control.

Step 1

Open the ULTI Home Control app.

Step 2

Press "Discover" and press in the top right-hand corner to search for gateway.




Step 3

Enter the password in the box below.

Default alias name: This is set by the technical consultant, so no need to change Default password: admin

(*applies only to un changed user info)



Step 4

Press the OK button and login to ULTI Home Control.

Out-of-home control

Set up out-of-home control by entering a link into the app.

Step 1

Go to the app's login page.

(if you are using the app, please select "Logout" to return to this page)

Step 2

Press "Manual" and enter the URL [DDNS] in the "Gateway" box. (DDNS information can be found in the reminder)



Step 3

Enter the alias name and password

Alias name: Defined by user Default password: admin

(*applies only to user info that has not been changed)


Step 4

Press the OK button and login to ULTI Home Control.

User interface

Homepage

Homepage includes control of various electronic devices:




1.Homepage

Create a shortcut to control home devices, such as lights, curtains, air-conditioning, TV equipment, scene modes and more. You can edit your own equipment shortcut on the homepage.

Control home devices


Step 1

Simply press the shortcut icon to control a specified device.



Create device shortcut

Step 1 Press the + icon




Step 2
Press and hold the device for two seconds and a shortcut will be added to the homepage.



Delete shortcut

Step 1

Press and hold the shortcut.



Step 2
Drag the shortcut to "Remove" at the top.



Modify shortcut size

Step 1

Press and hold the shortcut for about two seconds. You can then change the size by dragging the blue border shortcuts.



Step 2 After changing shortcut size, click the shortcut to complete modification.

Change shortcut icon

Users can change the shortcut icon to personal preference using the following methods:

Instant photo shoot, album or ULTI 4 built-in shortcut icons.

Step 1

Press the Scenes button.

Step 2

Click the "Scene" icon.



Step 3

Users can select an icon picture from the cameras, photo albums, or use a built-in ULTI 4 shortcut icon.



2. Scene


You can control multiple devices in scene mode by pressing just one button. For example, press the "All Off" button and the system will turn off all lights and curtains. Or you can select pre-set scene modes.

Step 1

Press 🔀 Scenes button.

Step 2

Press the On/Off key to trigger a specified scene mode.



3. Scheduling


The scheduling function allows you to turn a specified scene or device on/ off at a specified time.

Step 1


Press the O Scheduler button.

Step 2

Users can press the button to switch schedules on/off. (schedule on icon is green/schedule off icon is gray)




Click the "Schedule Name" to view scheduling content (scheduling content is for viewing purposes only and cannot be changed).



4. Devices

Choose different categories to control home devices such as lights, curtains, air-conditioning and television. Icons from left to right ontrol lighting, curtains, power adapter, double polar switch, TV and air-conditioning.



Lighting control

Step 1


Press the **Markovices** button, then press the "Lighting" button to control the lighting system.

Step 2

Simply press the on/off button to trigger a specified lighting control (this method is applicable only to on/off switch lamps).

Step 3

In the case of lamps with dimming functionality, you can switch lamps on/off and adjust luminosity by using the luminosity tuner bar. (100% represents the most light, while 0% represents turn off)



Curtain control

Step 1

Press the street button, then press the "Curtains" button to open and close the curtains.

Step 2 Click the open/close/stop button to control specified curtains.



Power adapter control

Step 1

Press the Rower Street Button, then press the Power Adapter button to trigger the power adapter.

Step 2

Users can adjust the bar to control a specified power adapter.




Double-pole switch control

Step 1

Press the **Movies** button, then press the "Double Pole" button to trigger the double-pole switch.

Step 2

Click "Double Pole" button to control a specified double-pole switch.



TV control

Step 1

Press the street button, then press the button to control TV equipment.

Step 2

Click the virtual television remote to control a specified TV.




Air-conditioning control

Step 1

Press the 🔀 🕬 button, then press the 🐺 button to control the air-con.

Step 2

Click the virtual air-con remote to control a specified air-con unit.



5. Logout

Disconnect the ULTI4 by using the logout function.

Step 1

Press the 🖒 Logout button.

Step 2

Press Yes to logout.



Reminder

Schneider ULTI Home Control App

User name:			
Gateway:			
Daccword*			

^{*}If you want to change the user login password, please call our service hotline on 1000.

